


REVERSE VIEW OF PICKUPS, SWITCH AND POTENTIOMETERS.




MANUFACTURED IN ENGLAND BY NSF CONTROLS LTD



Notes:-
 Positions 1, 2 & 3 are standard neck/both/bridge settings; positions 4, 5 & 6 are like the middle positions of a 5-way selector.
 Tone controls can be assigned differently, but in this diagram:-
 N-Tone control is active in positions 1, 2 & 4.
 M-Tone control is active in positions 4, 5 & 6.
 The pickup colour coding shown in this diagram does not represent any particular pickup manufacturer - please follow designations.

FRONT VIEW OF PICKUPS AND SWITCH




Scheme No 012 : Last Updated June 2013

REVERSE VIEW OF PICKUPS, SWITCH AND POTENTIOMETERS.



MANUFACTURED IN ENGLAND BY NSF CONTROLS LTD




Notes:-

Keep un-shielded wires as short as possible.

T1 tone control is active in positions 1, 2 & 3.
T2 tone control is active in positions 4, 5 & 6.

The pickup colour coding shown in this diagram does not represent any particular pickup manufacturer - please follow designations.

FRONT VIEW OF PICKUPS AND SWITCH




Scheme No 098 : Last Updated Dec 2014

REVERSE VIEW OF PICKUPS, SWITCH AND POTENTIOMETERS.

FREE-WAY SWITCH

www.freewayswitch.com

MANUFACTURED IN ENGLAND BY NSF CONTROLS LTD



HUMBUCKER COLOUR KEY	
1	NORTH Start wire —
2	NORTH Finish wire —
3	SOUTH Finish wire ---
4	SOUTH Start wire —


Notes:-

Positions 1, 2 & 3 are standard neck/both/bridge humbucker settings, positions 4, 5 & 6 are like the middle positions of a 5-way selector.

As an alternative, connect both 'CA' to 'CB' to vol pot. (remove grd. connection to 'CB') this will select 3 x single coils in position 5 and the middle + outer humbucker coils in positions 4 and 6.

The colour coding or magnetic polarity shown here does not represent any particular pickup manufacturer - please follow key.

FRONT VIEW OF PICKUPS AND SWITCH




Scheme No 141 : Last Updated Nov 2015

REVERSE VIEW OF PICKUPS, SWITCH AND POTENTIOMETERS.




MANUFACTURED IN ENGLAND BY NSF CONTROLS LTD



Notes:-
 Positions 1, 2 & 3 are standard neck/both/bridge humbucker settings, positions 4, 5 & 6 are like the middle positions of a 5-way selector.
 As an alternative, connect both 'CA' to 'CB' to vol pot. (remove grd. connection to 'CB') this will select 3 x single coils in position 5 and the middle + outer humbucker coils in positions 4 and 6.
 The colour coding or magnetic polarity shown here does not represent any particular pickup manufacturer - please follow key.

FRONT VIEW OF PICKUPS AND SWITCH




Scheme No 142 : Last Updated Nov 2015

REVERSE VIEW OF PICKUPS, SWITCH AND POTENTIOMETERS.



MANUFACTURED IN ENGLAND BY NSF CONTROLS LTD




Notes:-

Vol controls work as normal in positions 1-3. Middle pickup assigned to logical Vol/Tone controls in positions 4-6.

Use multi-core screened cable between switch and controls on LP-style guitars.

The pickup colour coding shown in this diagram does not represent any particular pickup manufacturer - please follow designations.

FRONT VIEW OF PICKUPS AND SWITCH




Scheme No 212 : Last Updated Apr 2017

REVERSE VIEW OF PICKUPS, SWITCH AND POTENTIOMETERS.



MANUFACTURED IN ENGLAND BY NSF CONTROLS LTD




Notes:-

Use multi-core screened cable between switch and controls on LP-style guitars.

The pickup colour coding shown in this diagram does not represent any particular pickup manufacturer - please follow designations.

FRONT VIEW OF PICKUPS AND SWITCH



Scheme No 213 : Last Updated Apr 2017